

CRT Socket Cross-Reference

NOTE: Always double-check socket type for your tube using the setup book/guide for your rejuvenator. The cross-reference works left to right (not right to left) and is intended for usage on Video Display tubes only. This cross-reference is incompatible for oscilloscope and projection tubes.

Example 1; oscilloscope tube 140CGB31 uses CR70 socket 2 but uses the UA on CR7000.

Example 2; projection tube 150AUB22 uses CR7000 socket 5 but uses socket 2 on CR70.

Sencore CR7000	B&K Precision	Sencore CR70	Sencore CR31
1	CR-23	3	23
2	CR-3	2	9
3	CR-70	UA	X111
4	CR-6	4	3
5	CR-31	13/UA	X23
6	CR-7	6	5

CR7000 sockets 7 & 8 are omitted because their only use is on projection tubes.

UA = Universal Adapter