



NOTE:
HORIZ. FREQUENCY IS SWITCHABLE BETWEEN 15KHZ AND 25KHZ. USUALLY USED IN THE 25KHZ MODE.

U5000 Block Diagram